



Service manual

Robin 600 LEDWash

Robin 600 PureWhite SW

Robin 600 PureWhite WW

Robin 600 PureWhite DL

Explosionszeichnung

Ersatzteil-Artikelübersicht


LMP Service

Wir bieten herstellerübergreifenden Service.
Unsere kostenlose Service-Hotline steht Ihnen von
Montag bis Donnerstag von 9.00 bis 17.30 Uhr
und Freitags von 9.00 bis 16.00 Uhr zur Verfügung.




Tel.: 05451/59 00-66 | Fax: 05451/59 00-69 | E-Mail: service@lmp.de


Version: 1 c




PRODUCT: Robin 600 LEDWash		
TITLE: Covers		
DOCUMENT: 99013068		
VERSION: 1	DATE: 25.05.2011	SHEET: 01 OF 10




PRODUCT: Robin 600 LEDWash		
TITLE: Covers of base		
DOCUMENT: 99013061		
VERSION: 1	DATE: 07.12.2010	SHEET: 02 OF 10





PRODUCT: Robin 600 LEDWash		
TITLE: Explode assembly		
DOCUMENT: 99013094,99013095,13030763		
VERSION: 1	DATE: 25.05.2011	SHEET: 04 OF 10




PRODUCT: Robin 600 LEDWash		
TITLE: Rear module of head		
DOCUMENT: 99013070		
VERSION: 1	DATE: 25.05.2011	SHEET: 05 OF 10




PRODUCT: Robin 600 LEDWash		
TITLE: Arm of head		
DOCUMENT: 99013066		
VERSION: 1	DATE: 25.05.2011	SHEET: 06 OF 10




PRODUCT: Robin 600 LEDWash		
TITLE: Arm of axe "Y"		
DOCUMENT: 99013066		
VERSION: 1	DATE: 25.05.2011	SHEET: 07 OF 10



PRODUCT: Robin 600 LEDWash		
TITLE: Axe "X"		
DOCUMENT: 99013063		
VERSION: 1	DATE: 07.12.2010	SHEET: 08 OF 10



PRODUCT: Robin 600 LEDWash		
TITLE: Front and rear panel of base		
DOCUMENT: 99013061		
VERSION: 1	DATE: 07.12.2010	SHEET: 09 OF 10



PRODUCT: Robin 600 LEDWash		
TITLE: Base		
DOCUMENT: 99013061		
VERSION: 1	DATE: 25.05.2011	SHEET: 10 OF 10

Rear Page Sheet 1 of 10

Page/Position	Part number	Part description	Device
1/1	18010033	Screw crosswise cup countersink M3x6	Robin 600 LEDWash
1/2	18010042	Screw socket head cap M6x20	Robin 600 LEDWash
1/3	18010118	Screw crosswise cup countersink M4x10	Robin 600 LEDWash
1/4	18020063	Screw self-tapping countersink 2,9x6,5	Robin 600 LEDWash
1/5	19010325-03	Cover of head (plastic)	Robin 600 LEDWash
1/6	19010326	Cover of arm (plastic)	Robin 600 LEDWash
1/7	19010327	Cover of base - grip (plastic)	Robin 600 LEDWash
1/8	19020081	Grip ROBE	Robin 600 LEDWash
1/9	99013057	Cover of base - assembled	Robin 600 LEDWash

Rear Page Sheet 2 of 10

Page/Position	Part number	Part description	Device
2/1	11030501-02	Cover of base	Robin 600 LEDWash
2/2	13051408	Spade terminal 4,8	Robin 600 LEDWash
2/3	18010159	Screw countersink inside hexagon M4x10	Robin 600 LEDWash
2/4	18040001	Nut M4 black	Robin 600 LEDWash
2/5	18050002	Washer M4 black	Robin 600 LEDWash
2/6	18050003	Washer M4 selflock - black	Robin 600 LEDWash
2/7	18050010	Washer M4 star - black	Robin 600 LEDWash

Rear Page Sheet 3 of 10

Page/Position	Part number	Part description	Device
3/1	11013563-01	Covering of plexiglass	Robin 600 LEDWash
3/2	12050573-01	Spacer hexagon	Robin 600 LEDWash
3/3	13030763	PCB RB2550 37 CREE-MCE	Robin 600 LEDWash
3/4	14060283-02	Cover plexiglass	Robin 600 LEDWash
3/5	17030628	O ring 2,9x1,78	Robin 600 LEDWash
3/6	18010008	Screw crosswise cup headed M3x8	Robin 600 LEDWash
3/7	18010016	Screw crosswise cup headed M3x6	Robin 600 LEDWash
3/8	18010035	Screw crosswise cup countersink M4x8	Robin 600 LEDWash
3/9	18010054	Screw crosswise cup headed M3x10	Robin 600 LEDWash
3/10	18010117	Screw crosswise cup countersink M3x12	Robin 600 LEDWash
3/11	18050001	Washer M3 black	Robin 600 LEDWash
3/12	18050009	Washer M3 selflock - black	Robin 600 LEDWash
3/13	19520085	EggCrate Robin 600 LEDWash (black)	Robin 600 LEDWash
3/14	99013094	LED module - lens FXLL-35A-A 35mm MC-	Robin 600 LEDWash
3/15	99013095	LED module - lens FCM-35A-0R RBX 35mm MC	Robin 600 LEDWash
3/16	10980101	Top Hat Robin 600 LEDWash (black)	Robin 600 LEDWash

Rear Page Sheet 4 of 10

Page/Position	Part number	Part description	Device
4/1	11013539-03	Holder of LED lens FXLL-35A-A 35mm MC-	Robin 600 LEDWash
4/2	11013541-01	Holder of LED lens FCM-35A-0R RBX 35mm MC	Robin 600 LEDWash
4/3	11013629	Locking (sheet metal)	Robin 600 LEDWash
4/4	12050609	Teflon housing	Robin 600 LEDWash
4/5	12050610	Interposer bar	Robin 600 LEDWash
4/6	14060288	LED lens FCM-35A-0R RBX 35mm MC	Robin 600 LEDWash
4/7	14060289-01	LED lens FXLL-35A-A 35mm MC-	Robin 600 LEDWash
4/8	18010008	Screw crosswise cup headed M3x8	Robin 600 LEDWash
4/9	13030818	PCB RB2550-A 7 MC	Robin 600 LEDWash
4/10	13030819	PCB RB2550-B 12 MC	Robin 600 LEDWash
4/11	13030820	PCB RB2550-C J3 9 MC	Robin 600 LEDWash
4/12	13030821	PCB RB2550-C J4 9 MC	Robin 600 LEDWash

Rear Page Sheet 5 of 10

Page/Position	Part number	Part description	Device
5/1	12050571-01	Extension of stepper motor "600"	Robin 600 LEDWash
5/2	13030779	PCB RB2510 Robin 600 LEDWash L	Robin 600 LEDWash
5/3	16010036	Stepper motor LINEAR ACTUATOR/600	Robin 600 LEDWash
5/4	16030038	Fan KD1209 PTBX 92x92x25 12V	Robin 600 LEDWash
5/5	17030627	Gasket 31010-0 PE 15x10	Robin 600 LEDWash
5/6	18010016	Screw crosswise cup headed M3x6	Robin 600 LEDWash
5/7	18010038	Screw crosswise cup headed M3x18	Robin 600 LEDWash
5/8	18050009	Washer M3 selflock - black	Robin 600 LEDWash
5/9	19040093	Antivibration gripping of fan	Robin 600 LEDWash
5/10	19530136	Cooler MC	Robin 600 LEDWash

Rear Page Sheet 6 of 10

Page/Position	Part number	Part description	Device
6/1	11013523-01	Stiffener of arm	Robin 600 LEDWash
6/2	11013524	Grounding of arm of axe "Y" right	Robin 600 LEDWash
6/3	11013525	Grounding of arm of axe "Y" left	Robin 600 LEDWash
6/4	17030028	Cube self-adhesive F0505 HC-101	Robin 600 LEDWash
6/5	18010023	Screw socket head cap M5x10	Robin 600 LEDWash
6/6	18010032	Screw crosswise cup countersink M3x8	Robin 600 LEDWash
6/7	18020016	Screw self-tapping countersink 2,9x6,5	Robin 600 LEDWash
6/8	99013063	Axe "X" - assembled	Robin 600 LEDWash
6/9	99013064	Arm of axe "Y" - stepper motor	Robin 600 LEDWash
6/10	99013174	Arm of axe "Y" - PCB	Robin 600 LEDWash

Rear Page Sheet 7 of 10

Page/Position	Part number	Part description	Device
7/1	11013528	Toothwheel D40	Robin 600 LEDWash
7/2	11013536-02	Holder of stepper motor	Robin 600 LEDWash
7/3	11013537-02	Key for axe "Y"	Robin 600 LEDWash
7/4	11013593	Washer D16 d8	Robin 600 LEDWash
7/5	11013595-01	Positioning wheel	Robin 600 LEDWash
7/6	12010202	Spacer D6xL9 M2	Robin 600 LEDWash
7/7	12040101	Toothwheel RPP3-03 D11 z12	Robin 600 LEDWash
7/8	12040102	Toothwheel D66 (inner diameter 16)	Robin 600 LEDWash
7/9	12050565	Holder ball-bearing	Robin 600 LEDWash
7/10	12050566	Insert of ball bearing	Robin 600 LEDWash
7/11	12050567-01	Pivot of ball bearing	Robin 600 LEDWash
7/12	12050593	Nut of stopper SW7 M4	Robin 600 LEDWash
7/13	13030761	PCB MH-1	Robin 600 LEDWash
7/14	13030778	PCB RB2006 Robin 600 LEDWash M	Robin 600 LEDWash
7/15	13030822	PCB MH-2	Robin 600 LEDWash
7/16	16010033	Stepper motor 17HC2001-01N -A	Robin 600 LEDWash
7/17	17010008	Ball bearing 6806-ZZ	Robin 600 LEDWash
7/18	17010015	Ball bearing 625 ZR-CMB SRI-2	Robin 600 LEDWash
7/19	17020010	Belt 420 RPP3/06	Robin 600 LEDWash
7/20	17040691-01	Holder of PCB with nuts	Robin 600 LEDWash
7/21	17050324	Holder of axe "Y" (Stepper motor) with nuts	Robin 600 LEDWash
7/22	17050327-01	Holder of axe "Y" (switch) with nuts	Robin 600 LEDWash
7/23	18010003	Screw crosswise cup headed M2x3	Robin 600 LEDWash
7/24	18010004	Screw socket head cap M4x10	Robin 600 LEDWash
7/25	18010007	Screw f. adjusting hexagon socket M4x5	Robin 600 LEDWash
7/26	18010010	Screw crosswise cup countersink M4x14	Robin 600 LEDWash
7/27	18010013	Screw socket head cap M4x25	Robin 600 LEDWash
7/28	18010016	Screw crosswise cup headed M3x6	Robin 600 LEDWash
7/29	18010033	Screw crosswise cup countersink M3x6	Robin 600 LEDWash
7/30	18010114	Screw crosswise cup countersink M2x6	Robin 600 LEDWash
7/31	18010118	Screw crosswise cup countersink M4x10	Robin 600 LEDWash
7/32	18010145	Screw crosswise cup headed M3x5	Robin 600 LEDWash
7/33	18020009	Screw self-tapping 2,9x6,5	Robin 600 LEDWash
7/34	18050002	Washer M4 black	Robin 600 LEDWash
7/35	18050003	Washer M4 selflock - black	Robin 600 LEDWash
7/36	18050009	Washer M3 selflock - black	Robin 600 LEDWash
7/37	18060039	Lock ring 3	Robin 600 LEDWash
7/38	18510246	Screw crosswise cup countersink M2x5	Robin 600 LEDWash

Rear Page Sheet 8 of 10

Page/Position	Part number	Part description	Device
8/1	11010490	Spring ring D46 d32 TI 0,32	Robin 600 LEDWash
8/2	11013528	Toothwheel D40	Robin 600 LEDWash
8/3	11013529	Holder of stepper motor "X"	Robin 600 LEDWash
8/4	11013530	Holder of axe "X" on base	Robin 600 LEDWash
8/5	11013531	Movement-stop "X"	Robin 600 LEDWash
8/6	12040100-01	Toothwheel D66 (inner diameter 32)	Robin 600 LEDWash
8/7	12040101	Toothwheel RPP3-03 D11 z12	Robin 600 LEDWash
8/8	12050561	Holder ball-bearing	Robin 600 LEDWash
8/9	12050562	Pivot "X" axe 2	Robin 600 LEDWash
8/10	12050563	Ring-plastic	Robin 600 LEDWash
8/11	12050564	Screw socket head cap M5x10 (stopper)	Robin 600 LEDWash
8/12	13030761	PCB MH-1	Robin 600 LEDWash
8/13	13051228	Microswitch SM 05L04B-Z	Robin 600 LEDWash
8/14	16010033	Stepper motor 17HC2001-01N -A	Robin 600 LEDWash
8/15	17010009	Ball bearing 6905-2RS	Robin 600 LEDWash
8/16	17020031	Belt HTD 03M-267	Robin 600 LEDWash
8/17	17030005	Lock ring No.:25	Robin 600 LEDWash
8/18	17030578	O ring 6x1,5	Robin 600 LEDWash
8/19	17040677	Grounding for holder of stepper motor	Robin 600 LEDWash
8/20	17040679	Holder of axe "X" B with nuts	Robin 600 LEDWash
8/21	17040680	Holder of switch	Robin 600 LEDWash
8/22	17050322	Holder of axe "X" with nuts AVDEL	Robin 600 LEDWash
8/23	18010003	Screw crosswise cup headed M2x3	Robin 600 LEDWash
8/24	18010007	Screw f. adjusting hexagon socket M4x5	Robin 600 LEDWash
8/25	18010016	Screw crosswise cup headed M3x6	Robin 600 LEDWash
8/26	18010040	Screw crosswise cup countersink M4x25	Robin 600 LEDWash
8/27	18010045	Screw crosswise cup countersink M4x35	Robin 600 LEDWash
8/28	18010076	Screw crosswise cup countersink M3x5	Robin 600 LEDWash
8/29	18020002	Screw self-tapping 2,9x9,5	Robin 600 LEDWash
8/30	18020009	Screw self-tapping 2,9x6,5	Robin 600 LEDWash
8/31	18040003	Nut selflock M5	Robin 600 LEDWash
8/32	18040020	Nut selflock M4 silver	Robin 600 LEDWash
8/33	18050001	Washer M3 black	Robin 600 LEDWash
8/34	18050002	Washer M4 black	Robin 600 LEDWash
8/35	18050006	Washer M5 selflock - black	Robin 600 LEDWash
8/36	18050007	Washer M5 black	Robin 600 LEDWash

Rear Page Sheet 9 of 10

Page/Position	Part number	Part description	Device
9/1	11013519	Underlay of front panel	Robin 600 LEDWash
9/2	12010198	Spacer D6xL4,5 M3	Robin 600 LEDWash
9/3	13030152	PCB EZ1051	Robin 600 LEDWash
9/4	13030760	PCB DMX Connectors RB2530	Robin 600 LEDWash
9/5	13030780	PCB Display QVGA Robin 600 LEDWash DS	Robin 600 LEDWash
9/6	13050070	Cable grommet F0705SR-6P1	Robin 600 LEDWash
9/7	13050103	Fuse socket - FGP1	Robin 600 LEDWash
9/8	17050323	Front panel with nuts	Robin 600 LEDWash
9/9	17050325	Rear panel with nuts	Robin 600 LEDWash
9/10	18010076	Screw crosswise cup countersink M3x5	Robin 600 LEDWash
9/11	18010118	Screw crosswise cup countersink M4x10	Robin 600 LEDWash
9/12	18010136	Screw crosswise cup countersink M3x16	Robin 600 LEDWash
9/13	18020002	Screw self-tapping 2,9x9,5	Robin 600 LEDWash
9/14	18040022	Nut selflock M3 silver	Robin 600 LEDWash
9/15	18050011	Washer M3 star - black	Robin 600 LEDWash

Rear Page Sheet 10 of 10

Page/Position	Part number	Part description	Device
10/1	12020018	Spacer D6xd3,8xL4	Robin 600 LEDWash
10/2	13020050	Power supply 48V/400W, 90-264V	Robin 600 LEDWash
10/3	13030149	PCB CNG-4 version "H"	Robin 600 LEDWash
10/4	13030782	PCB Con2E	Robin 600 LEDWash
10/5	13050171	Terminal end 7610-03/04	Robin 600 LEDWash
10/6	13051408	Spade terminal 4,8	Robin 600 LEDWash
10/7	16030044	Fan KD1206 PHB1 60x60x15	Robin 600 LEDWash
10/8	17030016	Rubber base GF2	Robin 600 LEDWash
10/9	17040672	Base plate with nuts Camloc	Robin 600 LEDWash
10/10	17040675-01	Grounding of axe "X" with nuts	Robin 600 LEDWash
10/11	17040676-02	Covering of power supply	Robin 600 LEDWash
10/12	17050326	Side panel with nuts	Robin 600 LEDWash
10/13	18010016	Screw crosswise cup headed M3x6	Robin 600 LEDWash
10/14	18010037	Screw crosswise cup headed M4x10	Robin 600 LEDWash
10/15	18010055	Screw crosswise cup headed M3x25	Robin 600 LEDWash
10/16	18010060	Screw crosswise cup headed M4x12	Robin 600 LEDWash
10/17	18010117	Screw crosswise cup countersink M3x12	Robin 600 LEDWash
10/18	18010118	Screw crosswise cup countersink M4x10	Robin 600 LEDWash
10/19	18010145	Screw crosswise cup headed M3x5	Robin 600 LEDWash
10/20	18020021	Screw self-tapping 3,5x13	Robin 600 LEDWash
10/21	18040001	Nut M4 black	Robin 600 LEDWash
10/22	18040005	Nut M3 black	Robin 600 LEDWash
10/23	18040022	Nut selflock M3 silver	Robin 600 LEDWash
10/24	18050002	Washer M4 black	Robin 600 LEDWash
10/25	18050003	Washer M4 selflock - black	Robin 600 LEDWash
10/26	18050010	Washer M4 star - black	Robin 600 LEDWash
10/27	18050011	Washer M3 star - black	Robin 600 LEDWash
10/28	99010420	Mounting bracket Omega CL assembled	Robin 600 LEDWash

Rear Page Sheet 11 of 13

List of spare parts specific to Robin 600 PureWhite SW. Rest of the parts as in Robin 600 LEDWash

Page/Position	Part number	Part description	Device
11/1	11613524	Grounding of arm of axe "Y" right - white	Robin 600 PureWhite SW
11/2	11613525	Grounding of arm of axe "Y" left - white	Robin 600 PureWhite SW
11/3	13030910	PCB RB2550 37 SW MC	Robin 600 PureWhite SW
11/4	13030983	PCB RB2006 Robin 600 PureWhite SW M	Robin 600 PureWhite SW
11/5	13030984	PCB RB2511 Robin 600 PureWhite SW L	Robin 600 PureWhite SW
11/6	13030985	PCB Display QVGA Robin 600 PureWhite SW DS	Robin 600 PureWhite SW
11/7	13031073	PCB Display QVGA Robin 600 PureWhite SW Wifi DS	Robin 600 PureWhite SW
11/8	13031104	PCB RB2550-A 7 SW MC	Robin 600 PureWhite SW
11/9	13031105	PCB RB2550-B 12 SW MC	Robin 600 PureWhite SW
11/10	13031106	PCB RB2550-C J3 9 SW MC	Robin 600 PureWhite SW
11/11	13031107	PCB RB2550-C J4 9 SW MC	Robin 600 PureWhite SW
11/12	17640803	Stiffener of arm with nuts - white	Robin 600 PureWhite SW
11/13	17650415	Front panel with nuts - white	Robin 600 PureWhite SW
11/14	18510010	Screw crosswise cup countersink M4x14	Robin 600 PureWhite SW
11/15	18510016	Screw crosswise cup headed M3x6	Robin 600 PureWhite SW
11/16	18510017	Screw crosswise cup headed M3x22	Robin 600 PureWhite SW
11/17	18510032	Screw crosswise cup countersink M3x8	Robin 600 PureWhite SW
11/18	18510033	Screw crosswise cup countersink M3x6	Robin 600 PureWhite SW
11/19	18510042	Screw socket head cap M6x20	Robin 600 PureWhite SW
11/20	18510055	Screw crosswise cup headed M3x25	Robin 600 PureWhite SW
11/21	18510073	Screw socket head cap M4x8	Robin 600 PureWhite SW
11/22	18510117	Screw crosswise cup countersink M3x12	Robin 600 PureWhite SW
11/23	18510118	Screw crosswise cup countersink M4x10	Robin 600 PureWhite SW
11/24	18510145	Screw crosswise cup headed M3x5	Robin 600 PureWhite SW
11/25	18510159	Screw countersink inside hexagon M4x10 brass	Robin 600 PureWhite SW
11/26	18510189	Screw socket head cap M3x16	Robin 600 PureWhite SW
11/27	19610326	Cover of arm (plastic) - white	Robin 600 PureWhite SW
11/28	19610327	Cover of base - grip (plastic) - white	Robin 600 PureWhite SW
11/29	19620081	Grip ROBE - white	Robin 600 PureWhite SW
11/30	19620085	EggCrate Robin 600 LEDWash - white	Robin 600 PureWhite SW
11/31	11613563-01	Covering of plexiglass "white"	Robin 600 PureWhite SW
11/32	11630501-02	Cover of base - white	Robin 600 PureWhite SW
11/33	17640672-01	Base plate with nuts Camloc - white	Robin 600 PureWhite SW
11/34	17650324-01	Holder of axe "Y" (Steppermotor) with nuts - white	Robin 600 PureWhite SW
11/35	17650325-02	Rear panel with nuts - white	Robin 600 PureWhite SW
11/36	17650327-02	Holder of axe "Y" (switch) with nuts - white	Robin 600 PureWhite SW
11/37	19610325-03	Cover of head (plastic) - white	Robin 600 PureWhite SW
11/38	19630136-02	Cooler MC - white	Robin 600 PureWhite SW

Rear Page Sheet 12 of 13

List of spare parts specific to Robin 600 PureWhite WW. Rest of the parts as in Robin 600 LEDWash

Page/Position	Part number	Part description	Device
12/1	11613524	Grounding of arm of axe "Y" right - white	Robin 600 PureWhite WW
12/2	11613525	Grounding of arm of axe "Y" left - white	Robin 600 PureWhite WW
12/3	13030893	PCB RB2550 37 WW MC	Robin 600 PureWhite WW
12/4	13030900	PCB Display QVGA Robin 600 PW WW/DL DS	Robin 600 PureWhite WW
12/5	13030901	PCB RB2006 Robin 600 PureWhite WW/DL M	Robin 600 PureWhite WW
12/6	13030902	PCB RB2511 Robin 600 PureWhite WW/DL L	Robin 600 PureWhite WW
12/7	13031298	PCB RB2550-A 7 WW MC	Robin 600 PureWhite WW
12/8	13031299	PCB RB2550-B 12 WW MC	Robin 600 PureWhite WW
12/9	13031300	PCB RB2550-C J3 9 WW MC	Robin 600 PureWhite WW
12/10	13031301	PCB RB2550-C J4 9 WW MC	Robin 600 PureWhite WW
12/11	17640803	Stiffener of arm with nuts - white	Robin 600 PureWhite WW
12/12	17650415	Front panel with nuts - white	Robin 600 PureWhite WW
12/13	18510010	Screw crosswise cup countersink M4x14	Robin 600 PureWhite WW
12/14	18510016	Screw crosswise cup headed M3x6	Robin 600 PureWhite WW
12/15	18510017	Screw crosswise cup headed M3x22	Robin 600 PureWhite WW
12/16	18510032	Screw crosswise cup countersink M3x8	Robin 600 PureWhite WW
12/17	18510033	Screw crosswise cup countersink M3x6	Robin 600 PureWhite WW
12/18	18510042	Screw socket head cap M6x20	Robin 600 PureWhite WW
12/19	18510055	Screw crosswise cup headed M3x25	Robin 600 PureWhite WW
12/20	18510073	Screw socket head cap M4x8	Robin 600 PureWhite WW
12/21	18510117	Screw crosswise cup countersink M3x12	Robin 600 PureWhite WW
12/22	18510118	Screw crosswise cup countersink M4x10	Robin 600 PureWhite WW
12/23	18510145	Screw crosswise cup headed M3x5	Robin 600 PureWhite WW
12/24	18510159	Screw countersink inside hexagon M4x10 brass	Robin 600 PureWhite WW
12/25	18510189	Screw socket head cap M3x16	Robin 600 PureWhite WW
12/26	19610326	Cover of arm (plastic) - white	Robin 600 PureWhite WW
12/27	19610327	Cover of base - grip (plastic) - white	Robin 600 PureWhite WW
12/28	19620081	Grip ROBE - white	Robin 600 PureWhite WW
12/29	19620085	EggCrate Robin 600 LEDWash - white	Robin 600 PureWhite WW
12/30	11613563-01	Covering of plexiglass "white"	Robin 600 PureWhite WW
12/31	11630501-02	Cover of base - white	Robin 600 PureWhite WW
12/32	13030900-01	PCB Display QVGA Robin 600 PW WW/DL Wifi DS	Robin 600 PureWhite WW
12/33	17640672-01	Base plate with nuts Camloc - white	Robin 600 PureWhite WW
12/34	17650324-01	Holder of axe "Y" (Steppermotor) with nuts - white	Robin 600 PureWhite WW
12/35	17650325-02	Rear panel with nuts - white	Robin 600 PureWhite WW
12/36	17650327-02	Holder of axe "Y" (switch) with nuts - white	Robin 600 PureWhite WW
12/37	19610325-03	Cover of head (plastic) - white	Robin 600 PureWhite WW
12/38	19630136-02	Cooler MC - white	Robin 600 PureWhite WW

Rear Page Sheet 13 of 13

List of spare parts specific to Robin 600 PureWhite DL. Rest of the parts as in Robin 600 LEDWash

Page/Position	Part number	Part description	Device
13/1	11613524	Grounding of arm of axe "Y" right - white	Robin 600 PureWhite DL
13/2	11613525	Grounding of arm of axe "Y" left - white	Robin 600 PureWhite DL
13/3	13030867	PCB RB2550 37 CW MC	Robin 600 PureWhite DL
13/4	13030900	PCB Display QVGA Robin 600 PW WW/DL DS	Robin 600 PureWhite DL
13/5	13030901	PCB RB2006 Robin 600 PureWhite WW/DL M	Robin 600 PureWhite DL
13/6	13030902	PCB RB2511 Robin 600 PureWhite WW/DL L	Robin 600 PureWhite DL
13/7	13031302	PCB RB2550-A 7 CW MC	Robin 600 PureWhite DL
13/8	13031303	PCB RB2550-B 12 CW MC	Robin 600 PureWhite DL
13/9	13031304	PCB RB2550-C J3 9 CW MC	Robin 600 PureWhite DL
13/10	13031305	PCB RB2550-C J4 9 CW MC	Robin 600 PureWhite DL
13/11	17640803	Stiffener of arm with nuts - white	Robin 600 PureWhite DL
13/12	17650415	Front panel with nuts - white	Robin 600 PureWhite DL
13/13	18510010	Screw crosswise cup countersink M4x14	Robin 600 PureWhite DL
13/14	18510016	Screw crosswise cup headed M3x6	Robin 600 PureWhite DL
13/15	18510017	Screw crosswise cup headed M3x22	Robin 600 PureWhite DL
13/16	18510032	Screw crosswise cup countersink M3x8	Robin 600 PureWhite DL
13/17	18510033	Screw crosswise cup countersink M3x6	Robin 600 PureWhite DL
13/18	18510042	Screw socket head cap M6x20	Robin 600 PureWhite DL
13/19	18510055	Screw crosswise cup headed M3x25	Robin 600 PureWhite DL
13/20	18510073	Screw socket head cap M4x8	Robin 600 PureWhite DL
13/21	18510117	Screw crosswise cup countersink M3x12	Robin 600 PureWhite DL
13/22	18510118	Screw crosswise cup countersink M4x10	Robin 600 PureWhite DL
13/23	18510145	Screw crosswise cup headed M3x5	Robin 600 PureWhite DL
13/24	18510159	Screw countersink inside hexagon M4x10 brass	Robin 600 PureWhite DL
13/25	18510189	Screw socket head cap M3x16	Robin 600 PureWhite DL
13/26	19610326	Cover of arm (plastic) - white	Robin 600 PureWhite DL
13/27	19610327	Cover of base - grip (plastic) - white	Robin 600 PureWhite DL
13/28	19620081	Grip ROBE - white	Robin 600 PureWhite DL
13/29	19620085	EggCrate Robin 600 LEDWash - white	Robin 600 PureWhite DL
13/30	11613563-01	Covering of plexiglass "white"	Robin 600 PureWhite DL
13/31	11630501-02	Cover of base - white	Robin 600 PureWhite DL
13/32	13030900-01	PCB Display QVGA Robin 600 PW WW/DL Wifi DS	Robin 600 PureWhite DL
13/33	17640672-01	Base plate with nuts Camloc - white	Robin 600 PureWhite DL
13/34	17650324-01	Holder of axe "Y" (Steppermotor) with nuts - white	Robin 600 PureWhite DL
13/35	17650325-02	Rear panel with nuts - white	Robin 600 PureWhite DL
13/36	17650327-02	Holder of axe "Y" (switch) with nuts - white	Robin 600 PureWhite DL
13/37	19610325-03	Cover of head (plastic) - white	Robin 600 PureWhite DL
13/38	19630136-02	Cooler MC - white	Robin 600 PureWhite DL